




ASSEMBLY INSTRUCTIONS MALIBU BENCH - ARMRESTS

STEP 1: ALIGN HOLE ON BACK OF ARMREST WITH THE HOLE ON THE FRONT SIDE OF THE BACK OF THE BENCH LEG. INSERT CARRIAGE BOLT INTO ARMREST AND THROUGH BENCH LEG. PLACE WASHER & NUT ON CARRIAGE BOLT. **DO NOT TIGHTEN!!**

STEP 2: ALIGN HOLE ON THE ARMREST WITH THE HOLE ON THE TOP SURFACE OF THE SEAT OF THE BENCH LEG. INSERT CARRIAGE BOLT INTO ARMREST AND THROUGH BENCH LEG. PLACE WASHER & NUT ON CARRIAGE BOLT. **DO NOT TIGHTEN!!**

STEP 3: REPEAT STEPS 1 & 2 FOR THE OTHER ARMREST.

STEP 4: NOW YOU MAY GO BACK AND FINISH TIGHTENING THE NUTS THE REST OF THE WAY. **BE CAREFUL NOT TO OVER TIGHTEN!!**

REF#	QTY	DESCRIPTION
1	2	ARMRESTS
	H6ARM	HARDWARE KIT
2	4	 5/16" X 3-1/2" SS CARRIAGE BOLT
3	4	 5/16" SS FLAT WASHER
4	4	 5/16" SS HEX NUT

Your 100% recycled plastic picnic table will give you many years of pleasure and pride, knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.

